

Component Locations

[J299 – Secondary Air Injection \(AIR\) pump relay \(2.8 ltr. engine\)](#)

[J299 – Secondary Air Injection \(AIR\) pump relay \(1.8 ltr. engine\)](#)