Component Locations

N – Ignition coil (1.8 ltr. engine)

N – Ignition coil (2.8 ltr. engine)