



22 **Ground Connection**

- on bulkhead, left, integral with Ground 28
- hydraulic unit Ground