



G45 Right front ABS wheel speed sensor

- in passenger side front wheel bearing housing
- driver's side –G47– shown