



### Knock Sensors 1 and 2 for cylinder bank 1

- 1 - Knock Sensor (KS) 1 -G61-, black: for cylinder 1 and 2
- 2 - Knock Sensor (KS) 2 -G66-, brown: for cylinder 3 and 4