



J207 **Starting Interlock Relay**

- location 13 on thirteenfold auxiliary relay panelautomatic transmission only