


Power outlets (12V)

from September 1997


Deviate relay location and fuseplacements as well as the locations of multiple connectors see section "component locations"

Relay location on the thirteen position auxiliary relay panel, above relay panel:




97-20676

Relay panel:



97-20515

Relay location on the eight position auxiliary relay panel, above relay panel:



97-25420

Power outlets (12V) - in luggage compartment

- S184 - Fuse for outlet I
- S185 - Fuse for outlet II
- U5 - 12V Socket
- U18 - 12V outlet -2-

(43) - Ground connection, on right B pillar, lower part

(75) - Ground connection, on right rear pillar

--- - Sedan only

- ws = white
- sw = black
- ro = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- ge = yellow
- or = orange